



Z41 PRO
TOUCH PANEL

Z41 LITE
TOUCH PANEL

Icon List


















































ZVI-Z41LIT

ZVI-Z41PRO

Application program version: [3.4]

Document Edition: [3.4]_a





















www.zennio.com

Nº	Name	Icon	Nº	Name	Icon	Nº	Name	Icon
1	No Icon		2	Off 1		3	On 1	
4	Off 2		5	On 2		6	Off 3	
7	On 3		8	Light Off 1		9	Light On 1	
10	Light Off 2		11	Light On 2		12	Light On/Off	
13	Light On/Off 2		14	Enter		15	Leave	
16	Cancel		17	Accept		18	Text Off	
19	Text On		20	Text On/Off		21	Unlock	
22	Lock		23	Down		24	Up	
25	Left		26	Right		27	Arrow Down	
28	Arrow Up		29	Arrow Right		30	Arrow Left	
31	Shutter Down 1		32	Shutter Up 1		33	Shutter Down 2	
34	Shutter Up 2		35	Shutter Open (Horizontal)		36	Shutter Close (Horizontal)	
37	Shutter Left 1		38	Shutter Left 2		39	Shutter Right 2	
40	Shutter Right 1		41	Door Closed		42	Door Open	
43	Window Closed		44	Window Open		45	Minus	
46	Plus		47	Cold/Warm		48	Cooling/Heating Off	
49	Cooling/Heating On		50	Temp Decrease		51	Temp Increase	

52	AC Off		53	AC On		54	AC On/Off	
55	AC On/Off 2		56	Mode Auto		57	Mode Heat	
58	Mode Cool		59	Mode Dry		60	Mode Fan	
61	Fan High		62	Fan Auto		63	Fan Low	
64	Fan Medium		65	Fan Very High		66	Fan Very Low	
67	Fan Stop 1		68	Fan Stop 2		69	Swing Move 1	
70	Swing Move 2		71	Swing Move 3		72	Swing Stop	
73	Auto 1		74	Auto 2		75	Auto 3	
76	Scene		77	Zero		78	One	
79	Two		80	Three		81	Four	
82	Five		83	Six		84	Seven	
85	Eight		86	Nine		87	Ten	
88	Eleven		89	Twelve		90	None	
91	All		92	All/None		93	Percentage: 0	
94	Percentage: 25		95	Percentage: 50		96	Percentage: 75	
97	Percentage: 100		98	Stop		99	Stop 2	
100	Play		101	Backward		102	Forward	
103	Previous		104	Next		105	Record	

106	Pause		107	Eject		108	Volume Down	
109	Volume Up		110	Sound Stop		111	Sound Play	
112	TV		113	Audio/Video		114	Auxiliary	
115	Clapperboard		116	Snapshot		117	Clock 1	
118	Clock 2		119	Clock Off 1		120	Clock On 1	
121	Clock Off 2		122	Clock On 2		123	Timer: Cyclical	
124	Timer: Once		125	Timer: Countdown		126	Sand Clock	
127	Set		128	Text OK		129	Comfort	
130	Standby		131	Economy		132	Building Protection	
133	Building Protection 2		134	Strong		135	Very Strong	
136	Warning		137	Warning: Hot		138	Warning: Cool	
139	Warning: Wind		140	Key 1		141	Key 2	
142	New		143	Setup		144	Tool	
145	Brightness Down		146	Brightness Up		147	Contrast Down	
148	Contrast Up		149	Schedule		150	Restart	
151	Themes		152	Ecologic		153	Melody 1	
154	Melody 2		155	Melody 3		156	Forbidden	
157	Zoom In		158	Zoom Out		159	Home	

160	Toilet		161	Bathroom		162	Library	
163	Kitchen		164	Bedroom		165	Study Room	
166	Living Room		167	Living Room 2		168	Laundry Room	
169	TV Room		170	Update		171	Graphics	
172	Clean		173	Trash		174	Radiant Floor Off	
175	Radiant Floor On		176	Phone: Add		177	Phone: Info	
178	Connection Error: Network		179	Connection Error: Internet		180	Connection Error: Service	
181	Connected to Remote Service		182	Phone Connected		183	Phone Connected 2	
184	Thermometer		185	Calendar		186	Calendar Page 1	
187	Calendar Page 2		188	Calendar Page 3		189	Calendar Page 4	
190	Arrow Up (Red)		191	Arrow Down (Red)		192	Arrow Up (Green)	
193	Arrow Down (Green)		194	Arrow Up (Blue)		195	Arrow Down (Blue)	
196	Arrow Up (White)		197	Arrow Down (White)		198	Right Indicator	
199	Left Indicator		200	Socket		201	Socket (Blue)	
202	Socket (Red)		203	Socket (Green)		204	Plug	
205	Information		206	Logic "And"		207	Logic "Or"	
208	Back		209	Welcome		210	Language	

211	Do Not Disturb		212	Make Up Room		213	Service	
214	Assistance		215	Emergency		216	Presence	
217	Leave 2		218	Swimming Pool		219	Swimming Pool 2	
220	Garden		221	Fountain		222	Garage	
223	Sauna		224	Sauna 2		225	Restaurant	
226	Sunrise		227	Midday		228	Sunset	
229	Sundown		230	Sundown 2				

Join and send us your inquiries
about Zennio devices:

<http://support.zennio.com>

Zennio Avance y Tecnología S.L.
C/ Río Jarama, 132. Nave P-8.11
45007 Toledo (Spain).

Tel. +34 925 232 002.

www.zennio.com
info@zennio.com



RoHS