

## **Versión 1.1**

- Primera versión.

## **Versión 1.2**

- Se añade el envío de los valores de intensidad y tensión tras solicitud de medidas de fase.
- Corrección de una incidencia: valores de energía incorrectos.
- Corrección de incidencias menores.
- Actualización de bloques funcionales.

## **Versión 1.3**

- Compatibilidad con un nuevo transformador de corriente (Ref. 9900045) para cables de hasta 36 mm de diámetro.
- Envío de factor de potencia
- Envío de frecuencia
- Parámetro de tiempo en las alarmas, para establecer cuánto tiempo debe mantenerse una situación de alarma antes de enviar el objeto de alarma.

## **Version 1.1**

- Initial version.

## **Version 1.2**

- Sending of intensity and voltage values after measure request added.
- Bug fix: wrong energy values.
- Minor bug fixes.
- Functional blocks updated.

## **Version 1.3**

- Compatibility with a new current transformer (ref. 9900045) which allows housing wires of up to 36 mm diameter.
- Inclusion of power factor sending parameters
- Inclusion of frequency sending parameters
- New time parameter in alarms configuration to set how long an alarm situation must be active before sending the alarm object.